

Partner: TiVo
Model: Series 3 HD
Device Type: DVR



GENERAL INFORMATION

SIMPLWINDOWS NAME:	TiVo Series 3 HD v1.1
CATEGORY:	DVR
VERSION:	1.1
SUMMARY:	Controls the TiVo Series 3 HD DVR.
GENERAL NOTES:	This module will provide control of the TiVo Series 3 HD DVR via TCP/IP by providing the same controls as the handheld remote as well as direct channel entry. Must use port 31339d in TCP/IP client definition. The TiVo MUST have at least v9.3a software installed.
CRESTRON HARDWARE REQUIRED:	C2NENET-1, C2NENET-2
SETUP OF CRESTRON HARDWARE:	TCP/IP Port 31339d is the default.
VENDOR FIRMWARE:	9.3a
VENDOR SETUP:	None
CABLE DIAGRAM:	N/A

CONTROL:

Up	D	Press for menu up.
Down	D	Press for menu down.
Left	D	Press for menu left.
Right	D	Press for menu right.
Select	D	Pulse for select.
TiVo	D	Pulse to goto TiVo menu.
LiveTV	D	Pulse to view live TV.
Thumbs_Up	D	Pulse for thumbs up user rating.
Thumbs_Down	D	Pulse for thumbs down user rating.

Partner: TiVo
Model: Series 3 HD
Device Type: DVR



Channel_Up	D	Pulse for channel up.
Channel_Down	D	Pulse for channel down.
Record	D	Pulse to record.
Display	D	Pulse to display channel information.
Aspect	D	Pulse to scroll through aspect ratios.
Key_*	D	Pulse to trigger digits 0 through 9.
Key_Enter	D	Pulse for enter function.
Key_Clear	D	Pulse for clear function.
Play	D	Pulse to play.
Pause	D	Pulse to pause.
Slow	D	Pulse for slow motion playback.
Reverse	D	Pulse to reverse scan. Pulse to jog reverse while in pause mode.
Forward	D	Pulse to forward scan. Pulse to jog forward while in pause mode.
Guide	D	Pulse to display guide.
Replay	D	Pulse to replay last 8 seconds of program.
Advance	D	Pulse to skip to live TV or back to beginning of viewing buffer.
Info	D	Pulse to display program information
Teleport_TiVo	D	Pulse to display TiVo menu.
Teleport_LiveTV	D	Pulse to view live TV.
Teleport_Guide	D	Pulse to display guide.
Teleport_NowPlaying	D	Pulse to view now playing list and recorded programs.
Direct_Channel_Dash	D	Pulse to enter dash for direct channel function.

Partner: TiVo
Model: Series 3 HD
Device Type: DVR



Direct_Channel_Enter	D	Pulse to send channel request to unit.
Direct_Channel_Back	D	Pulse to backspace one character in the outgoing Channel_Display\$ serial field.
Direct_Channel_Clear	D	Pulse to clear the outgoing Channel_Display\$ serial field.
Direct_Channel_Entry_*	D	Pulse to select channel number.
{{TCP/IP_Client_>>_Connect-F}}	D	Connect to "Connect-F" output from the TCP/IP client definition that will be communicating with the TiVo.
{{TCP/IP_Client_>>_status}}	A	Connect to the "status" output from the TCP/IP client definition that will be communicating with the TiVo.
{{TCP/IP_Client_>>_RX\$}}	S	Connect to the "RX\$" output from the TCP/IP client definition that will be communicating with the TiVo.

FEEDBACK:

Channel_Display\$	S	Serial output displaying current channel and channel changing status.
Connect-F	D	Indicates TCP/IP connection status with TiVo unit. Goes high if a connection is present.
status	A	Indicates details of TCP/IP status with regards to connection with TiVo unit: 0d = Not connected 1d = Waiting for connection 2d = Connected 3d = Connection failed 4d = Connection broken remotely 5d = Connection broken locally
{{Connect_>>_TCP/IP_Client}}	D	To be connected to the "Connect" input of the TCP/IP client definition that will be communicating with the TiVo.
{{TX\$_>>_TCP/IP_Client}}	S	To be connected to the "TX\$" input of the TCP/IP client definition that will be communicating with the TiVo.

PARAMETERS:

Port Number	A	This parameter is used by System Builder and has no effect when this module is being used in a program developed in Simpl Windows. Default is 31339d.
-------------	---	---

Partner: TiVo
Model: Series 3 HD
Device Type: DVR

**TESTING:**

OPS USED FOR TESTING:	v3.155.1240
SIMPL WINDOWS USED FOR TESTING:	v2.10.24
CRES DB USED FOR TESTING:	v19.2.5
SYMBOL LIBRARY USED FOR TESTING:	v538
SAMPLE PROGRAM:	TiVo Series 3 HD v1.1 Demo PRO2.smw
REVISION HISTORY:	v1.0 – Demo version v1.1 – Initial release